



ARGON ES 1.2x10 (VEOT-MCOG) USER MANUAL

Always Moving, Always Ready.

Thank you for purchasing this product. Please read this Guide first and keep it properly for future reference. We hope this product will meet your expectations.

Table of contents

01. Important	2
02. Illustrations	4
03. Appearance (P1~P2)	5
04. Quick Start	6
05. Language settings	6
06. Description on main screen	7
07. Menu	7
08. Item list	20
09. Guide for common troubleshooting	21
10. Storage and transportation	21
11. Two years limited warranty	22

1.Important

This Guide is a general guide for a series of products, which means that the product you receive may differ from the description in the Guide. The actual product you receive shall prevail.

This Guide is prepared to introduce our products to the users. We will try our best to ensure the accuracy of the Guide, but the completeness of the Guide still cannot be guaranteed, because our products have been continuously upgraded. We reserve the right to modify at any time without prior notice.



Android

iOS







Ρ1



Ρ2

No.	Name	Function		
1	Objective lens module	Infrared imaging		
		Power-off state	Long press: Power on	
2	Power button (confirm)	Power-on	Real-time defined) screen	Short press: Enter the menu (self defined) Long press: Screen off/power off
		status	Menu screen	Short press: Confirm Long press: return to the previous page
3	Microphone	Recording		
4	Eyepiece	Observation interface		
5	Sight distance adjustment	Adjust thevisual clarity of human eyes.		
6	Function knob	Move menu		
7	Data interface	Charging and data transmission		
8	Mounting hole	External fixation		
9	Triangular holder interface	Connecting triangle		
10	Hand strap band	Connect the hand strap		

04.Quick Start



05.Language settings



06. Description on main screen



WiFi 奈, Bluetooth 券, Video recording ⊡1, 2.0x Magnification, Audio ⊉, 10:30 Time, Battery power ✔ , Video recorded ♥ , Calibration succeeded ♥ , Photo taken ♥ 。

07.Menu





Take photos













Calibration



Ň Screen BRI





<u></u>













When enabled, the cursor will track the hottest point in the real time screen.

ाmage settings

Scene mode

- 1. The overall screen is gentle in natural mode;
- 2. The light and shade contrast will be enhanced in enhanced mode;
- 3. In highlight mode: The heat source target will be highlighted.



3





🖾 Image enhancement



📟 Stadiametric rangefinding

By turning the function knob, adjust the position of the upper horizontal line, to place the target in the image between the upper and lower horizontal lines. Then, the distance of the target will be automatically estimated by the device.

• Take the photo as an example:

For a deer as the target, the distance should be 91 meters away;









🗟 Calibration mode

Manual calibration: Short press the Power button for calibration operation.

Automatic calibration: The calibration operation will be performed automatically.

() General Settings

Language settings

English, русский, deutsch, français, español, italiano, slovenčina, 日本語、 ^か국의、 polski、 română、 norsk、 svenska、 dansk、 čeština、 magyar, suomalainen.

Unit settings

The units, meters and yards, are supported.





No operation is detected within 3 minutes

(c Timed shutdown



No operation is detected within the set time





No operation is detected within the set time



OSD



OSD 🗩





















After the device is screened off, the standbv icon will be displaved on the screen, as shown in the figure.





Enable the Bluetooth for automatic pairing. Once paired, the device can be controlled using a bluetooth remote control.





H Memory card formatting

Clear all the data, including the photos and videos.



고 Restore default

Restore all functions to the default state.



08. Item list





Data cable x 1

Quick operation manual x 1

Tarticle framphysics of boards a which proves para- and for the party of a solution if any firm which will be an with	
Ministrikanska di elemente in balan berahagi harara an Be antara di Maria antara antara di Antaria distanta antara di Antaria, se contatti di antara di Antari distanta antara di Antaria distanta antara di Antari distanta antara di Antaria distanta antara di Antaria distanta antara di Antaria di Antaria distanta antara di Antaria di Antaria di Antaria di Antaria di Antaria di Antaria di Antaria di Antaria di Antaria di Antaria di Antaria di Antaria di Antaria di Antari di Antaria di Antaria d	Product Certificati Namery Card
 Microsoften in and a labor information state, relating part proves the labor information spectrum in an and provide. 	



Warranty card x 1 Safety information sheet x 1

09. Guide for common troubleshooting

a) The device cannot be powered on.

Solution: Replace the battery or connect the adapter to power on.

b) Device prompts that it is disabled to take photos/videos.

Solution: The memory space of the device is full, and it is necessary to format the memory card or disconnect the device from the computer.

- c) The displayed time on the device does not match the actual time. Solution: Reset the time and date on the device in the menu.
- The screen turns off during use Solution: Short press the composite knob to wake up and light the screen.
- The device imaging is blurry during use Solution: Rotate the lens to manually focus until the display is clear.

10. Storage and transportation

Storage:

Storage conditions for the packaged product: well ventilated and clean indoor space at $30\sim 60^{\circ}$ C, with $\leq 95\%$ RH, and no condensed or corrosive gas;

Transportation:

Avoid rain, water invasion, upside down, violent vibration and impact during transportation.Handle with care and do not throw the product.

11. Two years limited warranty

Your owlset product is warranted free of defects in materials and workmanship for a period of 2 years from the time of purchase by the original purchaser. This warranty covers accidental damage, as well as any defects in materials and workmanship. Batteries, and damages caused by misuse or improper handling are not covered. In the event of a defect under this warranty, we promise to repair or replace your product and ship it back to you absolutely free of charge. Also, this warranty is null and void if modification or maintenance is provided by someone other than owlset. This warranty is non-transferable. For products not directly purchased from us, please contact the local dealer for an applicable warranty.

https://www.owlsetnv.com



